



INSTRUCTIONS FOR TOPTEC 15X30 FRAME CANOPY

STEP 1: Assemble frame as in diagram

- A. Assemble perimeters first. Note: when assembling fourth side, male-female Connection should be the final connection.
- B. Connect roof rafters.
- C. Connect clusters. Note: connect corner rafters to cluster first (longest tube on cluster) then intermediates.

STEP 2: Lay top over frame

STEP 3: Insert legs into the corner and intermediate brackets.

STEP 4: Attach tent to frame by means of side release buckles.

STEP 5: Raise tent to desired height.

NOTE: To disassemble reverse steps.